



### **IMPORTANT**

ASSEMBLE UNIT ON CHROME  
POLE IN THE FOLLOWING ORDER  
ONLY. REVERSE TO DISASSEMBLE

- ① POSITION WOODEN BASE. INSERT CHROME POLE. ADJUST FOR HEIGHT. ALWAYS USE SAFETY PIN IN POLE HOLES. TIGHTEN SET SCREWS IN FLANGE ON BASE. ALWAYS USE RUBBER MOUNTING DISC ON  $\frac{3}{4}$ " STUB SHAFT ON CHROME POLE
- ② PLACE POWER UNIT ON STUB SHAFT. INSERT ROD WITH MALE PLUG INTO POWER UNIT. TIGHTEN SET SCREW. CONNECT MALE + FEMALE PLUGS
- ③ INSTALL ALUMINUM CONE OVER ROD MAKING SURE THE SPIRAL TAPES ARE IN ALIGNMENT. PUT 3 SCREWS IN CONE WHERE IT JOINS THE POWER UNIT. TIGHTEN FIRMLY ONLY. DO NOT STRIP THREADS
- ④ MOUNT SAUCER ON TOP OF ALUMINUM CONE MAKE CERTAIN KEYED MALE + FEMALE SOCKETS ARE LINED UP CORRECTLY
- ⑤ MOUNT CLEAR PLEXIGLAS DOME ASSEMBLY ONTO SAUCER. MAKE CERTAIN MALE + FEMALE PLUGS ARE LINED UP CORRECTLY
- ⑥ CONNECT POWER CORD TO OUTLET

